

Timers - Multifunction

GAMMA series 16 functions 16 time ranges Connection of remote potentiometer possible Zoom voltage 24 to 240V AC/DC 2 change-over contacts Width 22.5mm



terminals A1-A2 (galvanically separated)

-20% to +25% -15% to +10%

48 to 400Hz

16 to 48Hz

4.5VA (1W)

>15% of the supply voltage III (in accordance with IEC 60661-1)

100%

500ms

Sinus

10%

4kV

Technical data

1. Functions

- 1 delayed contact (terminals 15-16-18) and
- 1 instantaneous contact (terminals 25-26-28)
 - E11 ON delay

Industrial design

- R11 OFF delay with control contact
- Es11 ON delay with control contact
- Wu11 Single shot leading edge voltage controlled
- Ws11 Single shot leading edge with control contact
- Wa11 Single shot trailing edge with control contact
- Bi11 Flasher pulse first
- Bp11 Flasher pause first

2 delayed contacts

- E20 ON delay
- R20 OFF delay with control contact
- Es20 ON delay with control contact
- Wu20 Single shot leading edge voltage controlled
- Ws20 Single shot leading edge with control contact
- Wa20 Single shot trailing edge with control contact
- Bi20 Flasher pulse first
- Bp20 Flasher pause first

2. Time ranges

Time range Adjustment range

ne range	, ajaoanon ango	
1s	50ms	1s
3s	150ms	3s
10s	500ms	10s
30s	1500ms	30s
1min	3s	1min
3min	9s	3min
10min	30s	10min
30min	90s	30min
1h	3min	1h
3h	9min	3h
10h	30min	10h
30h	90min	30h
1d	72min	1d
3d	216min	3d
10d	12h	10d
30d	36h	30d

3. Indicators

Green LED ON: Green LED flashes: Yellow LED ON/OFF:

4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN-Rail TS 35 according to EN 60715 Mounting position: any Shockproof terminal connection according to VBG 4 (PZ1 required), IP rating IP20 Tightening torque: max. 1Nm Terminal capacity:

indication of supply voltage

indication of time period

indication of relay output

- 1 x 0.5 to 2.5mm² with/without multicore cable end
- 1 x 4mm² without multicore cable end
- 2×0.5 to 1.5mm^2 with/without multicore cable end
- 2 x 2.5mm² flexible without multicore cable end

5. Input circuit Supply voltage: 24 to 240V AC/DC Tolerance: 24 to 240V DC 24 to 240V AC Rated frequency: 24 to 240V AC 48 to 240V AC Rated consumption: Duration of operation: Reset time: Wave form for AC: Residual ripple for DC: Drop-out voltage: Overvoltage category: Rated surge voltage:

6. Output circuit

 2 potential free change-over contacts

 Rated voltage:
 250V AC

 Switching capacity:
 750VA (3A / 250V AC)

 If the distance between the devices is less than 5mm!

Switching capacity: 1250VA (5A / 250V AC) If the distance between the devices is greater than 5mm!

5A fast acting

Fusing: Mechanical life: Electrical Life: Switching frequency:

20 x 10⁶ operations 2 x 10⁵ operations at 1000VA resistive load max. 60/min at 100VA resistive load max. 6/min at 1000VA resistive load (in accordance with IEC 60947-5-1) III (in accordance with IEC 60664-1) 4kV

Overvoltage category: Rated surge voltage:

7. Control contact

Activation: Potential free:

Loadable: Control voltage: Short circuit current: Line length: Control pulse length: bridge Y1-Y2 yes, basic isolation against input and output circuit no max. 5V max. 1mA max. 10m min. 50ms

8. Remote potentiometer (not included)

The internal potentiometer is de-activated when a remote potentio-meter is connected !!!

Line type: Control voltage: Short circuit current: Line length:

Connections:

 $1M\Omega$ potentiometer (type RONDO R2), terminals Z1-Y2 twisted pair max. 5V max. 5µA max. 5m

www.tele-online.com

G2ZMF11 24-240V

G2ZMF11 24-240V

Technical data

9. Accuracy Base accuracy:

Frequency response: Adjustment accuracy:

Repetition accuracy:

Voltage influence:

±1% (of maximum scale value) using $1M\Omega$ remote potentiometer

≤5% (of maximum scale value) using 1MQ remote potentiometer <0.5% or ±5ms

Temperature influence: ≤0.01% / °C

10. Ambient conditions Ambient temperature:

-25 to +55°C (in accordance with IEC 60068-1) -25 to +40°C (in accordance with UL 508) Storage temperature: -25 to +70°C Transport temperature: -25 to +70°C


Relative humidity: 15% to 85% (in accordance with IEC 60721-3-3 class 3K3) 3 (in accordance with IEC 60664-1) Pollution dearee: Vibration resistance: 10 to 55Hz 0 35mm (in accordance with IEC 60068-2-6) Shock resistance: 15g 11ms (in accordance with IEC 60068-2-27)

Functions

The internal potentiometer is de-activated when a remote-potentio-meter is connected ! The function has to be set before connecting the relay to the supply voltage.


ON delay (E11)

When the supply voltage U is applied, the instantaneous contact switches into on-position and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the delayed contact switches into on-position (yellow LED illuminated). This status remains until the supply voltage is interrupted. If the supply voltage is interrupted before the expiry of the interval t, the interval already expired is erased and is restarted when the supply voltage is next applied.



OFF delay with control contact (R11)


The supply voltage U must be constantly applied to the device (green LED illuminated). When the control contact Y1-Y2 is closed, both contacts switch into on-position (yellow LED illuminated). If the control contact is opened, the instantaneous contact switches into off-position and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the delayed contact switches into off-position (yellow LED not illuminated). If the control contact is closed again before the interval t has expired, the interval already expired is erased and is restarted with the next cycle.



ON delay with control contact (Es11)


The supply voltage U must be constantly applied to the device (green LED illuminated). When the control contact Y1-Y2 is closed, the instantaneous contact switches into on-position and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the delayed contact switches into on-position (yellow LED illuminated). This status remains until the control contact is opened again.

If the control contact is opened before the interval t has expired, the interval already expired is erased and is restarted with the next cycle.




Single shot leading edge voltage controlled (Wu11)

When the supply voltage U is applied, both contacts switch into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the delayed contact switches into off-position (yellow LED not illuminated). This status remains until the supply voltage is interrupted. If the supply voltage is interrupted before the interval t has expired, the both contacts switch into off-position. The interval already expired is erased and is restarted when the supply voltage is next applied.



Single shot leading edge with control contact (Ws11)

The supply voltage U must be constantly applied to the device (green LED illuminated). When the control contact Y1-Y2 is closed, both contacts switch into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the delayed contact switches into off-position (yellow LED not illuminated). The instantaneous contact remains in on-position, until the control contact is opened again. During the interval, the control contact (and the instantaneous contact) can be operated any number of times. A further cycle can only be started when the cycle run has been completed.




G2ZMF11 24-240V

Functions

Single shot trailing edge with control contact (Wa11)


The supply voltage U must be constantly applied to the device (green LED illuminated). When the control contact Y1-Y2 is closed the instantaneous contact switches into on-position. When the control contact is opened, the instantaneous contact switches into off-position, the delayed contact switches into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated), be delayed contact switches into off-position (yellow LED not illuminated). During the interval, the control contact (and the instantaneous contact) can be operated any number of times.

A further cycle can only be started when the cycle run has been completed.




Flasher pulse first (Bi11)

When the supply voltage U is applied, the instantaneous contact and the delayed contact switch into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired, the delayed contact switches into off-position (yellow LED not illuminated) and the set interval t begins again. The delayed contact is triggered at a ratio of 1:1 until the supply voltage is interrupted.




Flasher pause first (Bp11)

When the supply voltage U is applied, the instantaneous contact switches into on-position and the set interval t begins (green LED flashes). After the interval t has expired, the delayed contact switches into on-position (yellow LED illuminated) and the set interval t begins again. After the interval t has expired, the delayed contact switches into off-position (yellow LED not illuminated). The delayed contact is triggered at a ratio of 1:1 until the supply voltage is interrupted.




ON delay (E20)

When the supply voltage U is applied, the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the output relay R switches into on-position (yellow LED illuminated). This status remains until the supply voltage is interrupted. If the supply voltage is interrupted before the expiry of the interval t, the interval already expired is erased and is restarted when the supply voltage is next applied.




OFF delay with control contact (R20)

The supply voltage U must be constantly applied to the device (green LED illuminated). When the control contact Y1-Y2 is closed, the output relay R switches into on-position (yellow LED illuminated). If the control contact is opened, the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the output relay switches into off-position (yellow LED not illuminated). If the control contact is closed again before the interval t has expired, the interval already expired is erased and is restarted with the next cycle.




ON delay with control contact (Es20)

The supply voltage U must be constantly applied to the device (green LED illuminated). When the control contact Y1-Y2 is closed, the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the output relay R switches into on-position (yellow LED illuminated). This status remains until the control contact is opened again. If the control contact is opened before the interval t has expired, the interval already expired is erased and is restarted with the next cycle.




Single shot leading edge voltage controlled (Wu20)

When the supply voltage U is applied, the output relay R switches into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the output relay switches into off-position (yellow LED not illuminated). This status remains until the supply voltage is interrupted. If the supply voltage is interrupted before the interval t has expired, the output relay switches into off-position. The interval already expired is erased and is restarted when the supply voltage is next applied.



Single shot leading edge with control contact (Ws20)


The supply voltage Ü must be constantly applied to the device (green LED illuminated). When the control contact Y1-Y2 is closed, the output relay R switches into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired (green LED illuminated) the output relay switches into off-position (yellow LED not illuminated). During the interval, the control contact can be operated any number of times. A further cycle can only be started when the cycle run has been completed.



Functions


Single shot trailing edge with control contact (Wa20)

The supply voltage U must be constantly applied to the device (green LED illuminated). Closing the control contact Y1-Y2 has no influence on the condition of the output relay R. When the control contact is opened, the output relay switches into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired (green LED not illuminated), the output relay switches into off-position (yellow LED not illuminated). During the interval, the control contact can be operated any number of times. A further cycle can only be started when the cycle run has been completed.




Flasher pulse first (Bi20)

When the supply voltage U is applied, the output relay R switches into on-position (yellow LED illuminated) and the set interval t begins (green LED flashes). After the interval t has expired, the output relay switches into off-position (yellow LED not illuminated) and the set interval t begins again. The output relay is triggered at a ratio of 1:1 until the supply voltage is interrupted.




Flasher pause first (Bp20)


When the supply voltage U is applied, the set interval t begins (green LED flashes). After the interval t has expired, the output relay R switches into on-position (yellow LED illuminated) and the set interval t begins again. After the interval t has expired, the output relay switches into off-position (yellow LED not illuminated). The output relay is triggered at a ratio of 1:1 until the supply voltage is interrupted.



Dimensions



Connections





Subject to alterations and errors

